QUICK START

LitePro® 610/620

1 Rotate the CableWizard selector to expose the correct connectors for your computer.



Macintosh® or PowerBook™? →



IBM®-compatible PC? →



2 Plug the CableWizard into the projector.



3 Unplug the cable that connects your monitor to your computer.



4 Attach the CableWizard to your computer.



5 Plug the power cord into the projector and into an electrical outlet.



6 Turn on the projector. Turn on your monitor. Turn on your computer. Refer to the *LitePro 610/620 User's Guide* for more information.

InFocus® SYSTEMS

QUICK START

LitePro® 610/620

SAFETY SUMMARY: Please read these instructions before using your LitePro 610 or 620. Failure to comply could result in fire, electrical shock, personal injury or equipment damage.

Definition of Safety Icons on Product Labels

Refer to the User's Guide for more information.

Avoid hot surfaces.

Bulb explosion hazard.

Don't Look Into The Lens!
Be extremely careful not to look directly into the lens when the projector is on. The bright light can harm your eyes. Be especially careful to keep children from looking into the lens.

Don't Disassemble
Do not open the projector's case! Doing so exposes you to an electric shock hazard. Except for the projection lamp, there are no user-serviceable parts. All service must be performed by an In Focus Systems Authorized Service Provider.

Avoid Hot Surfaces
The rear of the projector becomes very hot during operation. Avoid touching the exhaust grill on the lamp door. Allow the projector to cool for at least 45 minutes before opening the lamp door to replace the lamp. The inside of the lamp housing can be very hot. Use extreme care. Avoid touching the hot surfaces inside.

Use Only The 610/620 Power Cord
Always use the power cord that came with the projector. Although other cords might look the same, they have not been safety-tested with the 610 or 620. Never use the power cord if it's damaged or frayed. When you disconnect the projector, always remove the power cord from the electrical outlet first, then from the projector.

Don't Defeat The Purpose Of The Grounding Plug
The projector is grounded through the grounding conductor on the power cord. To avoid electric shock, plug the power cord into a properly wired receptacle.

Avoid Liquid Spills
Don't set drinks on top of the projector. Spilled liquids can flow inside causing damage.

Don't Block Ventilation
Openings in the case provide ventilation to protect the projector from overheating. Keep loose papers and other objects away from the bottom, top and side grills. Don't place the projector on top of or close to a computer or other heat-producing equipment.

InFocus® SYSTEMS